

R Low-Cost, High-Capacity Disposable Bag-Sized Pleated Cartridge

Bag and basket in one easy to throw away element.

These new filter elements from Rosedale are easily installed in standard filtration housings, replacing both the basket and filter bag, with one unit that has much more surface area than standard bags. These elements look like a standard strainer basket, with an installed heavy duty cellulose pleat pack, having over 11 times the square footage of surface area than a standard bag. This provides maximum dirt retention capabilities at 99% (Beta 100) absolute ratings, at very low cost.

Features

- Basket Style housing seals like a standard strainer basket
- Cellulose Pleat Pack with over 50 square feet of surface area
- Metal support basket has 9/64" perforations for high flow rate
- Beta 100 (99%) absolute Micron Retention Levels
- Longer Element Life provides improved system efficiency

Benefits

- Fewer Change-outs required
- Less Downtime
- Improved quality due to improved retention ratings
- Lower Maintenance and Labor Costs
- Reduced Operator Exposure





How To Order

Build an ordering code as shown in the example

Example:

PB - 20 - 2

MODEL

Bag sized
pleated cartridge = **PB**

MICRON RETENTION LEVEL

75 Micron = **75**
 50 Micron = **50**
 30 Micron = **30**
 20 Micron = **20**
 10 Micron = **10**

CARTRIDGE SIZE/LENGTH

Standard Bag Size 1 = **1**
 Standard Bag Size 2 = **2**