

Turn Bag Housings Into Cartridge Filters!

Basket holds cartridges inside a bag housing!

Rosedale Products introduces a newly designed bag filter converter into which filter cartridges are installed. Thus, the bag filter can be quickly converted to a cartridge filter. Simply put, there are applications that call for a bag filter and others that call for a cartridge filter. Until now, it wasn't very easy to change between the two.

If it becomes necessary to change from bags to cartridges – install the Rosedale Converter Basket.

- Remove the original basket
- Install the new converter basket
- Load the cartridges
- Unique design prevents clean side contamination by removing basket from housing before removing cartridges from converter

You now have a cartridge filter able to utilize any standard cartridge.

Baskets fit standard models 4-12, 8-15, and 8-30 housings. Construction materials are either 304 stainless or 316 stainless steel.



Flow is introduced from above and circulates around ▲ cartridges. Fluid flows through cartridge walls, leaving contaminant on media, and "clean" fluid exits through bottom outlet.

How To Order

Build an ordering code as shown in the example below

EXAMPLE: **BC1 - S**

BASKET CONVERTER = BC ————

BASKET SIZE (IN INCHES, NOMINAL)

| OD | Length | |
|-----|--------|-----------------|
| 6.5 | 10 | = 1 ———— |
| 6.5 | 20 | = 2 |
| 4 | 10 | = 4 |

CONSTRUCTION MATERIALS

304 Stainless = **S** ————

316 Stainless = **S316**



Dimensions

| Housing Size & Cartridge Capacity | Model Code | OD* | Length* |
|-----------------------------------|------------|-----|---------|
| Model 4 1 cartridge | BC4 | 4 | 10 |
| Model 8 3 cartridges | BC1 | 6.5 | 10 |
| | BC2 | 6.5 | 20 |

*Nominal in inches

See pages 158-174 for more information on our cartridges.